


## **How Does it Work?**

## 5610/5616 Electric Actuator with DPS Positioner

This is a condensed version of how a typical Valworx quarter turn electric actuated valve functions when using the 5610/5616 series electric actuator with DPS positioner. It does not show fuses or other safety devices. The actuator will respond to a 4-20mA or 0-10VDC analog input control signal to control the actuator (valve) position 0-90° and flow 0-100%.





This technical bulletin is just an overview and simplified version, consult data sheets and installation instructions for detailed specifications.